



08/942,005








F/G. 3




F/G. 44





F/G. 5

			_										
	616				•	;	:	-:	<u></u>		_		
				_	-,,	Please ch	Please ch	<u>.</u>	Please ch				
	614				Details	lease	lease	lease	lease				
					-								
						The speed of the 1/0 slot fan i	e E	he	he	_			
	612					lot f	iot T	by t	by t				
						s 0/	<u>ه</u>	ified	ified				
						the I	the 1	dent	dent				
009					,	of	ŏ	VIQ	. yld				
	019	Ν			iptior	peed	peed	Sup	Sup.				
					escr	he s	hes	ower	ower			1	
					y		_	Œ	a.				
					Category Description	serious	serions	serions	serions				
					Cal	ser	ser	ser	ser				
	809							Nert	Mert				
						dert	dert	ply /	ply /			١	
					0,	an A	a no	Sup	Sup				
			/		Source	Slot Fan Alert	Slot Fan Alert	Power Supply Alert	Power Supply Alert			j	
					Š	1							
	909			•		per	per	er 4	er 4				
			di			stem	stem	temb	temb				
		(wo	Help			. Se	. Set	Sep	Sep				
		Wind	wopk			11: 29: 16AM Thu. September 4	Thu	2:04:27PM Thu September 4	Thu.				
		90-	Wil	_	me	16AM	17 AM	7PM	4PM				
	,604	<u> </u>	Μ̈Β		Date/Time	29:	29:	04:2	05: 1				
	101	tral	ogic		_	ł	1:	ći	ći				
		Cept	View LiveLogic MB Window	_	E L	-	7	7	80				
	-602	itro	×	i	Jame			•					
		Maestro Ceptral — (Log Window)		X	Server Name E	0	0	0	0	•			
			File		Ser	baba	baba	baba	papa				

F/G. 6







ALERT MANAGER TABLE /

SERVER 1 (NAME)

CPU ALERT DESCRIPTION: "CPU IDENTIFIED BY THE CPU NUMBER FAILED BECAUSE OF HIGH TEMPERATURE AND/OR LOW POWER"

NOTIFY YES/NO

SYSTEM BOARD FAN ALERT

NOTIFY YES/NO

TEMPERATURE SENSOR ALERT

NOTIFY YES/NO

POWER SUPPLY ALERT

NOTIFY YES/NO

ADAPTER ALERT

NOTIFY YES/NO

CANISTER ALERT

NOTIFY _____

SLOT FAN ALERT

NOTIFY ____

CANISTER FAN ALERT

NOTIFY ____

SERVER 2 (NAME)

CPU ALERT


NOTIFY YES/NO

(TYPICAL METHODS)

CALL ALERT MANAGER DIALOG MODULE 216

CALL ALERT FLASH DIALOG MODULE 218

-1006



08/942,005




FIG. 12